

TPMS Manager

Operating instructions



WABCO

Table of contents

Table of contents

1	List of abbreviations	5
2	Information about this document	6
2.1	Validity	6
2.2	Symbols used	6
3	Basic safety instructions	7
3.1	Proper use	7
3.2	Obvious misuse	7
3.3	Qualification and knowledge of personnel	7
3.4	Structure and explanation of warnings	8
3.4.1	Structure of the warning notes	8
3.4.2	Explanation of the warning notes	8
3.5	General safety instructions	9
3.6	Personal protection equipment	9
4	Scope of supply	10
5	Technical data	11
6	Structure	12
7	Start-up	13
8	Functions	14
8.1	ON/OFF/battery charge level	14
8.2	Checking the sensor	15
8.2.1	Read out sensor	15
8.2.2	Compatible WABCO sensors	16
8.2.3	Sequential learning of the sensors	16
8.3	Search part number	17
8.4	Settings	17
8.4.1	Region	17
8.4.2	Units	17
8.4.3	Format	17
8.4.4	Buzzer ON	17
8.4.5	Contrast	17
8.4.6	Auto OFF	18
8.5	Info	18
8.6	Language	18
8.7	Latest sensor data	18
9	Battery	19
9.1	Recharge	19
9.2	Replacement	19
10	Troubleshooting	19
11	Update software	20

Original document:

The German version is the original document.

Translation of the original document:

All non-German language editions of this document are translations of the original document.

Edition 2, Version 1 (10.2020)

Document no.: 815 010 248 3 (en)



You will find the current edition at:
<http://www.wabco.info/i/727>

Table of contents

12	Recycling	21
13	Disposal	22
14	WABCO regional offices	23

List of abbreviations

1 List of abbreviations

Abbreviation	Meaning
ABS	Acrylonitrile butadiene styrene (plastic)
AFM	Aftermarket - retrofitting, third-party manufacturers
LCD	Liquid Crystal Display
OE	Original Equipment (manufacturer)
SMS	Strap Mounted Sensor; internal tire pressure sensor, mounted on rim with tape
TPMS	Tire Pressure Monitoring System
WIS	Wheel Internal Sensor; internal tire pressure sensor, mounted on valve
WM	Wheel Mounted (sensor); external tire pressure sensor, mounted on rim

Information about this document

2 Information about this document

2.1 Validity

This document applies to the following WABCO part numbers:

300 200 001 0

2.2 Symbols used

 Important information, notes and/or tips

Descriptive text

- For individual action steps
 1. Action step 1
 2. Action step 2
 - ⇒ Consequence of an action
- Listing

Basic safety instructions

3 Basic safety instructions

3.1 Proper use

WABCO TPMS Manager is a battery-powered device for start-up and monitoring of commercial vehicle tire pressure sensors. The use of TPMS Manager does not replace tire pressure monitoring systems permanently installed in the vehicle.

3.2 Obvious misuse

The TPMS Manager must not be used for the start-up and monitoring of tire pressure sensors in passenger cars.

3.3 Qualification and knowledge of personnel

Trained specialist: A trained specialist is defined as someone who holds a recognised training certificate in the respective specialist field. The status may also apply to persons who have sufficient professional experience in the field to be able to assess and perform the tasks. Through the knowledge acquired, the trained specialist should be able to assess the tasks and implement them in compliance with the existing regulations, rules and guidelines.

Basic safety instructions

3.4 Structure and explanation of warnings

3.4.1 Structure of the warning notes

Warnings are structured as follows:

- Signal word and pictogram
- Correct naming of the hazard
- Description of the consequences if the hazard is ignored
- Description of the measure(s) to prevent the danger

3.4.2 Explanation of the warning notes

DANGER

Indicates a hazard that will result in death or serious injury if not avoided.

WARNING

Indicates a hazard that may result in death or serious injury if not avoided.

CAUTION

Indicates a hazard that may result in slight or moderately serious injury if not avoided.

NOTICE

Indicates a hazard that may result in material damage if not avoided.

Basic safety instructions

3.5 General safety instructions



WARNING

Danger to life when using the product with a pacemaker

This product emits electromagnetic and electronically generated waves that may interfere with the safe operation of pacemakers. People with pacemakers should never use this product.

- Follow all safety information, instructions and notices in this document to avoid personal injury and material damage.
- Follow regional and national regulations on accident prevention.
- Make sure your workplace is dry as well as adequately lit and ventilated.
- Secure the vehicle against rolling by using chocks.
- Ensure that the service brake is not being actuated when working on the brake.
- Attach a notice on the steering wheel stating that work is being carried out on the brake.
- Do not use the device near flammable liquids, explosive gases or vapours.
- Keep the machine away from heat sources.
- Do not use the machine with the battery cover removed.

3.6 Personal protection equipment

- Wear personal protective equipment to prevent injury:
 - Safety boots
 - Safety goggles

Scope of supply

4 Scope of supply



TPMS Manager



USB adapter



Connector type A



Connector type C



Connector type G



Connector type I



USB cable

Technical data

5 Technical data



Battery type:	Lithium-ion battery
Battery life:	Approx. 400 operations per full load
Dimensions (max. L, W, D):	16.5 cm x 9.5 cm x 3.8 cm
Housing material:	High impact resistant ABS
Response frequency:	Main frequencies: 315 MHz and 433.92 MHz (support for most specific frequencies)
Low battery indicator:	LCD bar display
Weight:	Approx. 1 kg
Temperature:	Operation: -20 °C to +55 °C Storage: -40 °C to +60 °C
Working height:	Up to 2000 m

Structure

6 Structure



ON/OFF switch



Read out sensor



Continue or confirm



Cancel, back



Navigate up



Navigate down



Navigate to the left



Navigate to the right



1 Antenna

2 Result lights

3 Trigger light

4 Battery charge indicator and light "Battery low"

5 Keyboard


Start-up

7 Start-up

- 1 - Fully charge your TPMS Manager.




- 2 - Download the PC software (WebVT).




- 3 - Unpack and install WebVT.



- 4 - Connect your TPMS Manager to your PC.



- 5 - Register your TPMS Manager.



- 6 - Update the software on your TPMS Manager.



Functions

8 Functions

8.1 ON/OFF/battery charge level

- Press the *ON/OFF switch* once to turn on the TPMS Manager.
⇒ The main menu is displayed.

Display battery charge level

- Press and hold the *ON/OFF switch* for **up to 3 seconds** to display the battery level.
or
- In the *INFO* menu, press *ON/OFF* to display the battery level permanently.

Switching off

- Press and hold the *ON/OFF switch* for **more than 3 seconds** to turn off the TPMS Manager.

Functions

8.2 Checking the sensor

There are 3 options to choose from:

- Select vehicle: Select sensor by vehicle manufacturer, model and year of manufacture.
- Select sensor: Select sensor by sensor manufacturer and model.
- Scan mode: Find sensor automatically.

8.2.1 Read out sensor

- Press *up* or *down* to select the wheel to be tested (optional function by means of which sensors can be assigned to a specific wheel. May be compulsory for some manufacturers. Follow the manufacturer's instructions.).
- Hold the TPMS Manager at a maximum distance of 30 cm from the sensor you want to check and press *Read out sensor*.
- Wait for the acoustic signal.
⇒ The sensor data is displayed.

Sensor data (example: WABCO WIS)

WABCO 1		
4217397556		0.0 BAR
22 °C	433 MHz	BAT:OK
REMAINING		120 MONTHS
() START		() MENU

Display	Explanation
421 739 755 6	Identification number of the sensor that was read out (ID)
22 °C	Temperature measured by sensor
120 MONTHS REMAINING	Remaining lifetime for a new sensor
0.0 bar	Pressure difference between tire interior and exterior
433 MHz	Radio frequency
BAT: OK	Battery status
START	Check again
MENU	Back to the main menu

 The battery status and temperature of internally mounted sensors are only displayed when the sensor is read. In trigger mode, only ID and pressure are displayed.

Functions

8.2.2 Compatible WABCO sensors

Name	Sensor type
WIS	Wheel Internal Sensor; internally mounted sensor, mounted on valve
SMS	Strap Mounted Sensor; internally mounted sensor, mounted on rim
WM 2.2	Externally mounted sensor, manufactured until calendar week 20 in 2017
WM 2.4	Externally mounted sensor, manufactured after calendar week 20 in 2017

Date of manufacture (example)




Calendar week	Year
23	2017

8.2.3 Sequential learning of the sensors

This chapter describes the process for WABCO sensors. Sensors from other manufacturers may have to be learned in a different way. Follow the manufacturer's instructions.

The OptiTire™ Diagnostic Software offers the possibility to learn sensors sequentially. If you use this function, the learning is performed counter-clockwise, starting with the front left-hand wheel. With twin wheels, the left wheel (in the direction of travel) is learned first.



Functions

8.3 Search part number

Identify sensor part numbers by vehicle manufacturer and display alternatives.

There are 3 options to choose from:

OE Part #: Original part

OE sensor reference: Alternative from the original equipment manufacturer

AFM Part: Reference number for retrofit parts

8.4 Settings

8.4.1 Region

Change the region in which the TPMS Manager is used.

8.4.2 Units

Change units for temperature and air pressure.

Supported units:

	Bar	Kilopascal	Pound per quarter inch
Celsius	bar / °C	kPa / °C	PSI / °C
Fahrenheit	bar / °F	kPa / °F	PSI / °F

8.4.3 Format

Display sensor ID in decimal, hexadecimal or manufacturer-specific (automatic).

8.4.4 Buzzer ON

The TPMS Manager may trigger a buzzer when checking a sensor. The buzzer can be switched on or off in the settings menu.

- Use *up*, *down*, *left* or *right* to switch between on and off.
- Click *OK* to confirm.

8.4.5 Contrast

Change screen contrast from 0 % to 100 %.

- Press *up*, *down*, *left* or *right* to increase the contrast.
- Press *down* to reduce the contrast.
- Click *OK* to confirm.

Functions

8.4.6 Auto OFF

The TPMS Manager can automatically turn itself off after a defined period of inactivity (1 minute to 60 minutes). The function can be disabled.

- Press *up*, *left* or *right* to increase the duration.
- Press *down* to reduce the duration (0 = DISABLED).
- Click *OK* to confirm.

8.5 Info

Display the current software version and information about the device.

Displayed information

Name	Explanation
SN	TPMS Manager serial number
Version	Current software version
Database	Revision status of the database (vehicles/sensors)
Receiver	Status of the installed receivers

8.6 Language

Change the language of all menus.

8.7 Latest sensor data

Display the most recently read sensor data. The data will be deleted when you restart. If the memory is empty, the machine displays the message "NO DATA".

Troubleshooting

9 Battery

Low battery indicator.

The TPMS Manager operates on 5 volts and has an integrated battery detection circuit. A fully charged battery can perform about 400 sensor tests (about 80-100 vehicles). A full charge takes about 6 hours.

9.1 Recharge



- Plug the USB cable into the USB port (1) on the TPMS Manager.
- Plug the USB cable into the charger adapter.
- Connect the charger adapter to a corresponding output.
 - ⇒ The red "CHARGING" LED lights up.
 - ⇒ After charging, the "CHARGING" LED lights up green.

i Using TPMS Manager when battery power is low is not recommended because data transmission may not be reliable.

9.2 Replacement

The TPMS Manager must be sent to your WABCO partner for battery replacement.

i Do not open the TPMS Manager or manipulate the seal on the TPMS Manager. As soon as the seal is broken, the guarantee becomes void.

10 Troubleshooting

If the TPMS Manager is unable to trigger one or more sensors, check the following possible causes:

- The vehicle has no sensor.
- The sensor, module or ECU itself may be damaged or defective.
- Your TPMS Manager may require a software update.
- Check the "Auto Off" time settings for the screen display.
- Your TPMS Manager is damaged or defective.

Update software

11 Update software

NOTICE

Damage to TPMS Manager when unplugging during the update process

Disconnecting the TPMS Manager or turning off the computer during the update process may cause damage to the TPMS Manager.

- Do not disconnect the TPMS Manager or turn off the computer during the update process.


 To update the system software, WebVT must be installed on your computer. For more information, please read chapter "7 Start-up", page 13.

Once a new log is available, the TPMS Manager must be updated.

- 1 - Fully charge your TPMS Manager.



- 2 - Connect your TPMS Manager to your PC.




- 3 - Update the software on your TPMS Manager.




Recycling

12 Recycling

Do not dispose of the lithium-ion battery or the device and/or accessories in the bin.



These components must be collected and recycled.



The crossed-out wheeled bin means that the product must be disposed of separately at the end of its life. This applies to your TPMS Manager, but also to all extensions marked with this symbol. Do not dispose of these products as unsorted household waste. For further information please contact WABCO.

13 Disposal

- The final and professional decommissioning and disposal of the product must be carried out in accordance with the applicable legal regulations of the country of use. In particular, the regulations for the disposal of batteries, equipment and the electrical system must be observed.
- Electrical appliances must be collected separately from household or commercial waste and recycled or disposed of in accordance with regulations.
- If applicable, take the old device to the company's internal disposal department, which will then forward it to specialist companies (specialist disposal companies).
- In principle, it is also possible to return the old device to the manufacturer. For this purpose, contact the manufacturer's customer service. Any special agreements must be observed.
- Electrical and electronic equipment must be collected separately from unsorted municipal waste and recycled or disposed of properly, because harmful substances can cause lasting damage to health and the environment if disposed of improperly.
- Detailed information can be obtained from specialist waste management companies or the responsible authorities.
- The packaging must be disposed of separately. Paper, cardboard and plastics must be recycled.

14 WABCO regional offices

	WABCO Headquarters, Giacomettistrasse 1, 3006 Bern 31, Switzerland, Tel.: +32-2663 98 00				
	WABCO Europe BVBA Chaussée de la Hulpe 166 1170 Brüssel Belgium Tel.: +32 2 663 9800 Fax: +32 2 663 9896		WABCO Belgium BVBA/SPRL 't Hofveld 6 B1-3 1702 Groot-Bijgaarden Belgium Tel.: +32 2 481 09 00		WABCO Austria GesmbH Rappachgasse 42 1110 Wien Austria Tel.: +43 1 680 700
	WABCO GmbH Am Lindener Hafen 21 30453 Hannover Germany Tel.: +49 511 9220		WABCO GmbH Gartenstraße 1 31028 Gronau Germany Tel.: +49 511 922 3000		WABCO Radbremesen GmbH Bärlochweg 25 68229 Mannheim Germany Tel.: +49 621 48310
	WABCO brzdy k vozidlům spol. s r.o. Sourcing & Purchasing Office U Trezorky 921/2 Prague 5 Jinonice 158 00 Prag Czech Republic Tel.: +420 226 207 010		WABCO brzdy k vozidlům spol. s r.o. Pražákova 1008/69, Štýřice, 639 00 Brno Czech Republic Tel.: +420 543 428 800		WABCO Automotive BV Rhijnspoor 263 Capelle aan den IJssel (Rotterdam) 2901 LB The Netherlands Tel.: +31 10 288 86 00
	WABCO (Schweiz) GmbH Morgenstrasse 136 Bern 3018 Switzerland Tel.: +41 31 997 41 41		WABCO International Sourcing & Purchasing Office Harmandere Mh. Dedepasa Cd. 24 Atlas Park B/5 Pendik, 34912 Istanbul Turkey Tel.: +90 216 688 81 72 Fax: +90 216 688 38 26		WABCO Sales Office Halide Edip Adivar Mh. Ciftecevizler Deresi Sok. 2/2 Akin Plaza, Sisli, 34382 Istanbul Turkey Tel.: +90 212 314 20 00 Fax: +90 212 314 20 01
	WABCO France Carre Hausmann 1 cours de la Gondaire 77600 Jossigny France Tel.: +33 1 87 21 13 12		WABCO Automotive Italia S.r.L. Studio Tributario e Societario, Galleria San Federico 54 Torino, 10121 Italy Tel.: +39 011 4010 411		WABCO Polska Sp. z o.o. ul. Ostrowskiego 34 53-238 Wroclaw Poland Tel.: +48 71 78 21 888
	WABCO España S. L. U. Av de Castilla 33 San Fernando de Henares Madrid 28830 Spain Tel.: +34 91 675 11 00		WABCO Automotive AB Drakegatan 10, Box 188 SE 401 23 Gothenburg Sweden Tel.: +46 31 57 88 00		WABCO Automotive U.K. Ltd Unit A1 Grange Valley Grange Valley Road, Batley, W Yorkshire, United Kingdom, WF17 6GH Tel.: +44 (0)1924 595 400

WABCO regional offices

	WABCO Australia Pty Ltd Unit 3, 8 Anzed Court Mulgrave, Victoria 3170 Australia Tel.: +61 3 8541 7000 Hotline: 1300-4-WABCO		WABCO do Brasil Indústria e Comércio De Freios Ltda Rodovia Anhanguera, km 106 CEP 13180-901 Sumaré-SP Brazil Tel.: +55 19 2117 4600 Tel.: +55 19 2117 5800		WABCO Hong Kong Limited 14/F Lee Fund Centre 31 Wong Chuk Hang Road Hong Kong China Tel.: +852 2594 9746
	Asia Pacific Headquarters, WABCO (Shanghai) Mgmt Co. Ltd 29F & 30F, Building B, New Caohejing Intl Bus. Center 391 Guiping Rd, Xuhui Dist. Shanghai 200233, China Tel.: +86 21 3338 2000		WABCO (China) Co. Ltd. Jinan Shandong WABCO Automotive Products Co. Ltd. 1001 Shiji Av, Jinan Indust. Zone, Shandong 250104 China Tel.: +86 531 6232 8800		WABCO (China) Co. Ltd No. 917 Weihe Road, Economic & Tech. Dev. Zone Qingdao 266510 China Tel.: +86 532 8686 1000
	WABCO (China) Co. Ltd Guangdong WABCO FUHUA Automobile Brake System Co. Ltd. Building E, No. 1 North, Santai Av, Taishan City Guangdong 529200 China Tel.: +86 750 5966 123		Shanghai G7 WABCO IOT Technology Co. Ltd Room 503, Ligu Building, No. 255 Wubao Road, Minhang Dist. Shanghai 201100 China Tel.: 021-64058562/826		China-US RH Sheppard Hubei Steering Systems Co. Ltd No. 18, Jingui Road, Xianning City Hubei 437000 China
	WABCO India Limited Plot No. 3 (SP), III Main Road Ambattur Industrial Estate Chennai 600 058 India Tel.: +91 44 42242000		WABCO Japan Inc Gate City Ohsaki W. Tower 2F, 1-11-1, Osaki, Shinagawa-ku, Tokyo 141-0032 Japan Tel.: +81 3 5435 5711		WABCO Korea Ltd 23, Cheongbulsandan-ro, Cheongbuk-eup Pyongtaek-si Gyeonggi-do, 17792 Korea Tel.: +82 31 680 3707
	WABCO Asia Private Ltd 25 International Business Park #03-68/69 German Centre 609916 Singapore Tel.: +65 6562 9119		WABCO Automotive SA 10 Sunrock Close Sunnyrock Ext 2, Germison 1401 PO Box 4590, Edenvale 1610 South Africa Tel.: +27 11 450 2052		WABCO Middle East and Africa FZCO Vehicle Control System DWC Business Park, Building A3, Room NO: 115, PO Box 61231, Dubai United Arab Emirates E-mail: info.dubai@wabco-auto.com



You can find information on WABCO products here: <https://www.wabco-customercentre.com>
Please contact your WABCO partner for further information.

ZF Friedrichshafen AG

ZF is a global technology company and supplies systems for passenger cars, commercial vehicles and industrial technology, enabling the next generation of mobility. ZF allows vehicles to see, think and act. In the four technology domains Vehicle Motion Control, Integrated Safety, Automated Driving, and Electric Mobility, ZF offers comprehensive solutions for established vehicle manufacturers and newly emerging transport and mobility service providers. ZF electrifies different kinds of vehicles. With its products, the company contributes to reducing emissions and protecting the climate.

ZF, which acquired WABCO Holdings Inc. on May 29, 2020, now has 162,000 employees worldwide with approximately 260 locations in 41 countries. In 2019, the two then-independent companies achieved sales of €36.5 billion (ZF) and \$3.4 billion (WABCO).

With the integration of WABCO, the leading global supplier of braking control systems and other advanced technologies that improve the safety, efficiency and connectivity of commercial vehicles ZF will create a new level of capability to pioneer the next generation of solutions and services for original equipment manufacturers and fleets globally. WABCO, with almost 12,000 people in 40 locations worldwide, will now operate under the ZF brand as its new Commercial Vehicle Control Systems division.



WABCO