




























N°	M2 SYSTEM	SYSTEM NUMBER	PEDAL UNIT	CLUTCH		OVER CENTER SPRING	RETURN SPRING	RELIEF VALVE	RUBBER PAD	HOSE		HEAT PROTECTION	SLAVE CYLINDER	CHARACTERISTICS 	WARNING
				SYNCHRO	NO SYNCHRO					NUMBER	LENGTH (m)				
1	HSS (PULL TYPE) + SLAVE	400 030 004 0 FL P/N A02-13131-000	965 001 103 0 FL P/N A02-13074-006								452 698 011 0 FL P/N A02-13132-000	1.70		965 001 108 0  FL P/N A02-13074-004 965 001 208 0  FL P/N A02-14079-000 965 001 209 0  FL P/N A02-14078-001 965 001 058 0  FL P/N A02-14020-000  965 001 332 0  FL P/N A12-34145-000 DO NOT ACTIVATE, IF THE CLUTCH CONTROL SYSTEM IS FILLED AND NOT MOUNTED ON A CLUTCH	
2	HSS (PUSH TYPE) + SLAVE	400 030 005 0 FL P/N A02-13131-001	965 001 104 0 FL P/N A02-13074-007												
3	HUS SYSTEM + SLAVE	400 030 027 0 FL P/N A02-14080-000	965 001 106 0 FL P/N A02-14078-000								452 698 012 0 FL P/N A02-13132-001	2.20			
4	HUS OCS SYSTEM +SLAVE	400 030 009 0 FL P/N A02-13131-003	965 001 108 0 FL P/N A02-13074-004												
5	HSS (PULL TYPE) + SLAVE	400 030 011 0 FL P/N A02-13131-004	965 001 103 0 FL P/N A02-13074-006								452 698 013 0 FL P/N A02-13132-002	1.96			
6	HSS (PUSH TYPE) + SLAVE	400 030 012 0 FL P/N A02-13131-007	965 001 104 0 FL P/N A02-13074-007												
7	HUS SYSTEM + SLAVE	400 030 028 0 FL P/N A02-14080-001	965 001 106 0 FL P/N A02-14078-000								452 698 014 0 FL P/N A02-13132-003	2.40			
8	HUS OCS SYSTEM + SLAVE	400 030 014 0 FL P/N A02-13131-005	965 001 108 0 FL P/N A02-13074-004												
9	HUS OCS SYSTEM + SLAVE	400 030 029 0 FL P/N A02-14080-002	965 001 209 0 FL P/N A02-14078-001								452 698 012 0 FL P/N A02-13132-001	2.20			
10	HUS OCS SYSTEM + SLAVE	400 030 030 0 FL P/N A02-14080-003	965 001 209 0 FL P/N A02-14078-001								452 698 014 0 FL P/N A02-13132-003	2.40			
11	HUS OCS SYSTEM + SLAVE	400 030 032 0 FL P/N A02-14081-001	965 001 209 0 FL P/N A02-14078-001								452 698 007 0 FL P/N	2.40			
12	HUS OCS SYSTEM + SLAVE	400 030 031 0 FL P/N A02-14081-000	965 001 209 0 FL P/N A02-14078-001								452 698 008 0 FL P/N 02-13965-001	1.9			

N°	P3 SYSTEM	SYSTEM NUMBER	PEDAL UNIT	CLUTCH		OVER CENTER SPRING	RETURN SPRING	RELIEF VALVE	RUBBER PAD	HOSE		HEAT PROTECTION	SLAVE CYLINDER	CHARACTERISTICS
				SYNCHRO	NO SYNCHRO					NUMBER	LENGTH (m)			
1	HUS OCS SYSTEM +SLAVE	400 030 033 0 FL P/N A02-14082-000	965 001 208 0 FL P/N A02-14079-000							452 698 012 0 FL P/N A02-13132-001	2.20		970 051 503 0 FL P/N 02-13133-000	EACH PRODUCT SEE OUTLINE DRAWING DOC. 005
2	HUS OCS SYSTEM +SLAVE	400 030 034 0 FL P/N A02-14082-001	965 001 208 0 FL P/N A02-14079-000							452 698 014 0 FL P/N A02-13132-003	2.40			
3	HUS OCS SYSTEM +SLAVE	400 030 023 0 FL P/N -	965 001 208 0 FL P/N A02-14079-000							452 698 015 0 FL P/N A02-13132-004	2.10			
4	HUS OCS SYSTEM +SLAVE	400 030 051 0 FL P/N A02-14022-000	965 001 058 0 FL P/N A02-14020-000							452 698 012 0 FL P/N A02-13132-001	2.20			
5	HUS OCS SYSTEM +SLAVE	400 030 036 0 FL P/N A02-14082-002	965 001 208 0 FL P/N A02-14079-000							452 698 007 0 FL P/N -	2.40			
6	HUS OCS SYSTEM +SLAVE	400 030 037 0 FL P/N A02-14082-003	965 001 208 0 FL P/N A02-14079-000							452 698 008 0 FL P/N 02-13965-001	1.90			
7	HUS OCS SYSTEM +SLAVE	400 030 038 0 FL P/N A12-34112-000	965 001 332 0 FL P/N A12-34145-000							452 698 012 0 FL P/N A02-13132-001	2.20			
8	HUS OCS SYSTEM +SLAVE	400 030 039 0 FL P/N A12-34112-001	965 001 332 0 FL P/N A12-34145-000							452 698 014 0 FL P/N A02-13132-003	2.40			
9	HUS OCS SYSTEM +SLAVE	400 030 041 0 FL P/N A12-34112-002	965 001 332 0 FL P/N A12-34145-000							452 698 008 0 FL P/N 02-13965-001	1.90			

