

Sensor Externo (WM2)

Imagen	Referencia	Ø Eje Pernos fijación	Taladro pernos
	960 731 011 0	335 mm	26 mm
	960 731 013 0	335 mm	23 mm
	960 731 017 0	335 mm	23 mm
	960 731 021 0	335 mm	32 mm
	960 731 081 0	225 mm	26 mm
	960 905 820 4 960 905 821 4	335 mm	26 mm 32 mm
	960 731 801 0		960 731 804 0
	960 731 802 0		960 731 822 0



ECU OptiTire
446 220 110 0



Soporte ECU
446 220 000 4



Comprobador OptiTire
300 200 001 0

Sensor Interno con juego de válvulas (WIS)

	960 732 000 0
	960 732 100 0 Llanta Acero
	960 732 102 0 Llanta Acero
	960 732 104 0 Llanta Aluminio
	960 732 105 0 Llanta Aluminio
	960 732 117 0 Llanta Aluminio

Sensor Interno con correa (SMS)

	<p>960 733 000 0 Sensor 960 733 117 0 Correa 17.5" 960 733 119 0 Correa 19.5" 960 733 122 0 Correa 22.5" 960 733 124 0 Correa 24.5"</p>
--	---



Software Diagnosis
246 301 730 0

Cables

Imagen	Referencia	Denominación
	449 925 253 0	Cable ELEX - SmartBoard y OptiTire
	449 913 XXX 0	Cable IVTM
	449 916 XXX 0	Cable SmartBoard y OptiTire
	449 927 XXX 0	Cable OptiTire GIO 5
	449 934 330 0	Cable OptiLink - OptiTire y SmartBoard
	449 944 217 0	Cable OptiLink - OptiTire y caja mando ECAS
	894 600 001 2	Cable Adaptor OptiTire / OptiLink



OptiTire Descripción de Sistema
815 040 229 3



Pegatina OptiTire
813 000 003 3