





MEASURING POINT :	DISCHARGE PORT	0 =	INLET PORT	9 =	COOLANT CONNECTION
MESSPUNKT :	DRUCKANSCHLUSS		SAUGANSCHLUSS		KUEHMITTELANSCHLUSS
POINT DE MESURE :	REFOULEMENT		ASPIRATION		CONNEXION DE FLUIDE DE REFRIGERATION
PUNTO DI MISURA :	COMPRESSIONE		ASPIRAZIONE		COLLEGAMENTO LIQUIDO REFRIGERANTE
FREE FROM ASBESTOS		2 =	DISCHARGE PORT		
ASBESTFREI			DRUCKANSCHLUSS		
EXEMPT D'AMIANTE			REFOULEMENT		
ESENTE D'AMIANTO			COMPRESSIONE		

8. 1 = OIL SUPPLY
DRUCKOELANSCHLUSS
ORIFICE D'ARRIVEE D'HUILE
ORIFIZIO D ARRIVO OLIO

8. 2 = OIL DRAIN
OELRUECKLAUF
RETOUR D'HUILE
RITORNO OLIO