

AFTERMARKET PROGRAMMING

ECU CROSS REFERENCE



TP19061

WABCO

General Information

How to use the ECU Cross Reference

Given ABS ECU part numbers are frequently updated, the original ABS ECU part number may not correctly identify the required configuration file for programming a new replacement ECU.

Please use the ECU Cross Reference List to identify the most updated, correct part number to use in the "ECU Part Number Being Replaced" field on the Snap-on website.

Original ABS ECU Part Number	Fields on Snap-on website (https://wabco.snapon.com)	
(NOTE: This will not work on wabco.snapon.com)	ECU Part Number Being Replaced (The part number must be entered to identify the configuration file to download)	New ECU Part Number (Programmable ECU)
400 850 326 0	400 864 304 0	400 864 009 0
400 850 327 0	400 864 305 0	400 864 009 0
400 850 340 0	400 864 305 0	400 864 009 0
400 850 092 0	400 864 360 0	400 864 009 0
400 850 102 0	400 864 360 0	400 864 009 0
400 850 103 0	400 864 360 0	400 864 009 0
400 850 138 0	400 864 360 0	400 864 009 0
400 850 139 0	400 864 360 0	400 864 009 0
400 850 160 0	400 864 360 0	400 864 009 0
400 850 161 0	400 864 360 0	400 864 009 0
400 850 168 0	400 864 360 0	400 864 009 0
400 850 169 0	400 864 360 0	400 864 009 0

Part Details

VIN*
All 17 Characters

ECU Part Number Being Replaced*
10 Digits (400xxxxx0)

New ECU Part Number*
10 Digits (400xxxxx0)

I have read the limitations above and confirm that this vehicle supports J1939 communications.

Find Configuration

ECU Cross Reference List

Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number	Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number
400 850 326 0	400 864 304 0	400 864 009 0	400 850 104 0	400 864 400 0	400 864 011 0
400 850 327 0	400 864 305 0	400 864 009 0	400 850 105 0	400 864 400 0	400 864 011 0
400 850 340 0	400 864 305 0	400 864 009 0	400 850 137 0	400 864 400 0	400 864 011 0
400 850 092 0	400 864 360 0	400 864 009 0	400 850 140 0	400 864 400 0	400 864 011 0
400 850 102 0	400 864 360 0	400 864 009 0	400 850 141 0	400 864 400 0	400 864 011 0
400 850 103 0	400 864 360 0	400 864 009 0	400 850 159 0	400 864 400 0	400 864 011 0
400 850 138 0	400 864 360 0	400 864 009 0	400 850 162 0	400 864 400 0	400 864 011 0
400 850 139 0	400 864 360 0	400 864 009 0	400 850 163 0	400 864 400 0	400 864 011 0
400 850 160 0	400 864 360 0	400 864 009 0	400 850 167 0	400 864 400 0	400 864 011 0
400 850 161 0	400 864 360 0	400 864 009 0	400 850 170 0	400 864 400 0	400 864 011 0
400 850 168 0	400 864 360 0	400 864 009 0	400 850 171 0	400 864 400 0	400 864 011 0
400 850 169 0	400 864 360 0	400 864 009 0	446 004 602 0	400 864 400 0	400 864 011 0
446 004 601 0	400 864 360 0	400 864 009 0	400 850 090 0	400 864 400 0	400 864 011 0
400 850 089 0	400 864 360 0	400 864 009 0	400 850 406 0	400 864 401 0	400 864 011 0
400 850 106 0	400 864 360 0	400 864 009 0	400 850 703 0	400 866 337 0	400 866 164 0
400 850 107 0	400 864 360 0	400 864 009 0	400 866 009 0	400 866 337 0	400 866 164 0
400 850 108 0	400 864 360 0	400 864 009 0	400 866 228 0	400 866 341 0	400 866 164 0
400 850 142 0	400 864 360 0	400 864 009 0	400 866 241 0	400 866 342 0	400 866 164 0
400 850 143 0	400 864 360 0	400 864 009 0	400 850 871 0	400 866 343 0	400 866 164 0
400 850 144 0	400 864 360 0	400 864 009 0	400 866 001 0	400 866 343 0	400 866 164 0
400 850 164 0	400 864 360 0	400 864 009 0	400 866 086 0	400 866 344 0	400 866 164 0
400 850 165 0	400 864 360 0	400 864 009 0	400 866 930 0	400 866 346 0	400 866 164 0
400 850 166 0	400 864 360 0	400 864 009 0	400 850 629 0	400 866 347 0	400 866 164 0
400 850 172 0	400 864 360 0	400 864 009 0	400 866 002 0	400 866 347 0	400 866 164 0
400 850 173 0	400 864 360 0	400 864 009 0	400 850 335 0	400 866 351 0	400 866 164 0
400 850 174 0	400 864 360 0	400 864 009 0	400 866 229 0	400 866 351 0	400 866 164 0
446 004 618 0	400 864 360 0	400 864 009 0	400 850 630 0	400 866 352 0	400 866 164 0
446 004 619 0	400 864 360 0	400 864 009 0	400 866 003 0	400 866 352 0	400 866 164 0
446 004 620 0	400 864 360 0	400 864 009 0	400 866 071 0	400 866 353 0	400 866 164 0
446 004 625 0	400 864 360 0	400 864 009 0	400 866 236 0	400 866 354 0	400 866 164 0
400 850 099 0	400 864 361 0	400 864 009 0	400 850 661 0	400 866 356 0	400 866 164 0
400 850 098 0	400 864 361 0	400 864 009 0	400 866 004 0	400 866 356 0	400 866 164 0
446 004 603 0	400 864 361 0	400 864 009 0	400 850 631 0	400 866 357 0	400 866 164 0
446 004 605 0	400 864 362 0	400 864 009 0	400 850 645 0	400 866 357 0	400 866 164 0
400 850 323 0	400 864 364 0	400 864 009 0	400 850 670 0	400 866 357 0	400 866 164 0
400 850 337 0	400 864 365 0	400 864 009 0	400 866 005 0	400 866 357 0	400 866 164 0
400 850 366 0	400 864 366 0	400 864 009 0	400 850 612 0	400 866 360 0	400 866 164 0
400 864 003 0	400 864 368 0	400 864 009 0	400 866 237 0	400 866 360 0	400 866 164 0
400 850 325 0	400 864 303 0	400 864 011 0	400 850 870 0	400 866 361 0	400 866 164 0
400 850 338 0	400 864 303 0	400 864 011 0	400 866 006 0	400 866 361 0	400 866 164 0
400 850 091 0	400 864 400 0	400 864 011 0	400 850 632 0	400 866 362 0	400 866 164 0
400 850 087 0	400 864 400 0	400 864 011 0	400 866 007 0	400 866 362 0	400 866 164 0
400 850 088 0	400 864 400 0	400 864 011 0	400 850 613 0	400 866 363 0	400 866 164 0
400 850 097 0	400 864 400 0	400 864 011 0	400 866 238 0	400 866 363 0	400 866 164 0
400 850 101 0	400 864 400 0	400 864 011 0	400 866 909 0	400 866 364 0	400 866 164 0

ECU Cross Reference List

Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number	Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number
400 866 906 0	400 866 365 0	400 866 164 0	400 866 035 0	400 866 459 0	400 866 167 0
400 850 641 0	400 866 468 0	400 866 164 0	400 866 235 0	400 866 460 0	400 866 167 0
400 850 663 0	400 866 468 0	400 866 164 0	400 866 908 0	400 866 461 0	400 866 167 0
400 850 669 0	400 866 468 0	400 866 164 0	400 866 077 0	400 866 462 0	400 866 167 0
400 850 671 0	400 866 468 0	400 866 164 0	N/A	400 866 270 0	400 866 167 0
400 850 825 0	400 866 468 0	400 866 164 0	N/A	400 866 520 0	400 866 167 0
400 866 164 0	401 866 468 0	400 866 164 0	N/A	400 866 521 0	400 866 167 0
400 866 010 0	400 866 468 0	400 866 164 0	N/A	400 866 522 0	400 866 167 0
N/A	400 866 530 0	400 866 164 0	400 866 084 0	400 866 329 0	400 866 168 0
400 866 920 0	400 866 321 0	400 866 165 0	400 866 231 0	400 866 330 0	400 866 168 0
400 850 710 0	400 866 322 0	400 866 165 0	400 866 095 0	400 866 331 0	400 866 168 0
400 866 018 0	400 866 322 0	400 866 165 0	400 866 070 0	400 866 332 0	400 866 168 0
400 866 074 0	400 866 324 0	400 866 165 0	400 850 640 0	400 866 333 0	400 866 168 0
400 850 665 0	400 866 326 0	400 866 165 0	400 866 075 0	400 866 333 0	400 866 168 0
400 850 804 0	400 866 326 0	400 866 165 0	400 866 073 0	400 866 334 0	400 866 168 0
400 850 668 0	400 866 326 0	400 866 165 0	400 866 038 0	400 866 313 0	400 866 169 0
400 866 019 0	400 866 326 0	400 866 165 0	400 866 099 0	400 866 314 0	400 866 169 0
400 866 902 0	400 866 328 0	400 866 165 0	400 866 085 0	400 866 315 0	400 866 169 0
N/A	400 866 518 0	400 866 165 0	400 866 905 0	400 866 315 0	400 866 169 0
400 850 708 0	400 866 301 0	400 866 166 0	400 866 926 0	400 866 316 0	400 866 169 0
400 866 012 0	400 866 301 0	400 866 166 0	400 866 089 0	400 866 317 0	400 866 169 0
400 850 868 0	400 866 302 0	400 866 166 0	400 866 910 0	400 866 317 0	400 866 169 0
400 866 013 0	400 866 302 0	400 866 166 0	400 866 017 0	400 866 318 0	400 866 169 0
400 850 650 0	400 866 303 0	400 866 166 0	400 866 922 0	400 866 319 0	400 866 169 0
400 866 014 0	400 866 303 0	400 866 166 0	400 864 550 0	400 864 623 0	400 864 005 0
400 866 072 0	400 866 304 0	400 866 166 0	400 864 501 0	400 864 623 0	400 864 005 0
400 866 039 0	400 866 305 0	400 866 166 0	400 865 001 0	400 865 162 0	400 865 043 0
400 866 900 0	400 866 305 0	400 866 166 0	400 865 002 0	400 865 163 0	400 865 043 0
400 850 651 0	400 866 307 0	400 866 166 0	400 865 003 0	400 865 164 0	400 865 043 0
400 850 869 0	400 866 307 0	400 866 166 0	400 865 004 0	400 865 165 0	400 865 043 0
400 866 015 0	400 866 307 0	400 866 166 0	400 866 269 0	400 865 165 0	400 866 165 0
400 850 633 0	400 866 308 0	400 866 166 0	400 850 839 0	400 865 166 0	400 865 043 0
400 866 016 0	400 866 308 0	400 866 166 0	400 865 005 0	400 865 166 0	400 865 043 0
N/A	400 866 167 0	400 866 167 0	400 850 672 0	400 865 167 0	400 865 043 0
400 866 064 0	400 866 448 0	400 866 167 0	400 850 787 0	400 865 167 0	400 865 043 0
400 866 911 0	400 866 449 0	400 866 167 0	400 850 826 0	400 865 167 0	400 865 043 0
400 866 076 0	400 866 450 0	400 866 167 0	400 850 836 0	400 865 167 0	400 865 043 0
400 866 034 0	400 866 451 0	400 866 167 0	400 865 006 0	400 865 167 0	400 865 043 0
400 866 098 0	400 866 452 0	400 866 167 0	400 865 030 0	400 865 171 0	400 865 043 0
400 866 933 0	400 866 453 0	400 866 167 0	400 865 034 0	400 865 173 0	400 865 043 0
400 866 036 0	400 866 454 0	400 866 167 0	N/A	400 865 203 0	400 865 043 0
400 866 078 0	400 866 455 0	400 866 167 0	400 850 331 0	400 865 196 0	400 865 043 0
400 866 923 0	400 866 456 0	400 866 167 0	400 865 011 0	400 865 176 0	400 865 044 0
400 866 025 0	400 866 457 0	400 866 167 0	400 850 729 0	400 865 176 0	400 865 044 0
400 866 907 0	400 866 458 0	400 866 167 0	400 850 827 0	400 865 177 0	400 865 044 0

ECU Cross Reference List

Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number	Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number
400 850 837 0	400 865 177 0	400 865 044 0	446 003 718 0	400 864 601 0	400 864 008 0
400 865 012 0	400 865 177 0	400 865 044 0	400 850 094 0	400 864 602 0	400 864 008 0
400 850 730 0	400 865 195 0	400 865 044 0	400 850 111 0	400 864 602 0	400 864 008 0
400 865 039 0	400 865 145 0	400 865 045 0	400 850 146 0	400 864 602 0	400 864 008 0
400 865 021 0	400 865 146 0	400 865 045 0	400 850 154 0	400 864 602 0	400 864 008 0
400 865 041 0	400 865 147 0	400 865 045 0	400 850 157 0	400 864 602 0	400 864 008 0
400 850 731 0	400 865 148 0	400 865 045 0	446 003 702 0	400 864 602 0	400 864 008 0
400 865 009 0	400 865 148 0	400 865 045 0	446 003 719 0	400 864 602 0	400 864 008 0
400 865 024 0	400 865 149 0	400 865 045 0	400 864 510 0	400 864 604 0	400 864 008 0
400 865 018 0	400 865 151 0	400 865 045 0	400 850 315 0	400 864 662 0	400 864 008 0
N/A	400 865 151 0	400 865 045 0	400 850 330 0	400 864 662 0	400 864 008 0
N/A	400 865 183 0	400 865 045 0	400 850 343 0	400 864 662 0	400 864 008 0
N/A	400 865 184 0	400 865 045 0	400 865 031 0	400 865 131 0	400 865 052 0
N/A	400 865 186 0	400 865 045 0	400 850 707 0	400 865 134 0	400 865 052 0
400 865 022 0	400 865 178 0	400 865 047 0	400 850 767 0	400 865 136 0	400 865 052 0
400 865 023 0	400 865 179 0	400 865 047 0	400 865 035 0	400 865 187 0	400 865 052 0
400 865 007 0	400 865 155 0	400 865 048 0	400 865 040 0	400 865 188 0	400 865 052 0
N/A	400 865 207 0	400 865 048 0	446 106 225 0	400 868 103 0	400 868 007 0
N/A	400 865 201 0	400 865 048 0	400 868 003 0	400 868 103 0	400 868 007 0
400 850 829 0	400 865 159 0	400 865 013 0	400 869 021 0	400 868 121 0	400 868 009 0
400 850 830 0	400 865 160 0	400 865 013 0	400 851 021 0	400 868 121 0	400 868 009 0
400 850 838 0	400 865 160 0	400 865 013 0	446 106 205 0	400 868 121 0	400 868 009 0
N/A	400 865 200 0	400 865 013 0	400 868 021 0	400 868 121 0	400 868 009 0
400 850 334 0	400 865 158 0	400 865 013 0	400 851 023 0	400 868 123 0	400 868 009 0
400 865 025 0	400 865 144 0	400 865 014 0	400 869 023 0	400 868 123 0	400 868 009 0
400 865 027 0	400 865 197 0	400 865 014 0	446 106 223 0	400 868 123 0	400 868 009 0
N/A	400 865 204 0	400 865 015 0	400 868 023 0	400 868 123 0	400 868 009 0
400 850 095 0	400 864 603 0	400 864 007 0	400 868 026 0	400 868 124 0	400 868 009 0
400 850 096 0	400 864 603 0	400 864 007 0	400 850 301 0	400 860 100 0	400 860 000 0
400 850 112 0	400 864 603 0	400 864 007 0	400 850 621 0	400 860 100 0	400 860 000 0
400 850 147 0	400 864 603 0	400 864 007 0	446 106 201 0	400 860 100 0	400 860 000 0
400 850 155 0	400 864 603 0	400 864 007 0	400 850 071 0	400 860 100 0	400 860 000 0
400 850 158 0	400 864 603 0	400 864 007 0	400 850 302 0	400 860 100 0	400 860 000 0
446 003 703 0	400 864 603 0	400 864 007 0	446 106 202 0	400 860 100 0	400 860 000 0
446 003 720 0	400 864 603 0	400 864 007 0	400 850 072 0	400 860 102 0	400 860 000 0
400 850 316 0	400 864 603 0	400 864 007 0	400 850 303 0	400 860 102 0	400 860 000 0
400 850 328 0	400 864 603 0	400 864 007 0	400 850 351 0	400 860 102 0	400 860 000 0
400 864 504 0	400 864 667 0	400 864 008 0	446 106 203 0	400 860 102 0	400 860 000 0
400 864 502 0	400 864 668 0	400 864 008 0	400 850 403 0	400 860 102 0	400 860 000 0
400 850 093 0	400 864 601 0	400 864 008 0	446 106 211 0	400 860 103 0	400 860 000 0
400 850 110 0	400 864 601 0	400 864 008 0	400 850 307 0	400 860 104 0	400 860 000 0
400 850 145 0	400 864 601 0	400 864 008 0	400 850 308 0	400 860 105 0	400 860 000 0
400 850 153 0	400 864 601 0	400 864 008 0	N/A	400 860 111 0	400 860 000 0
400 850 156 0	400 864 601 0	400 864 008 0	446 106 208 0	400 860 850 0	400 860 003 0
446 003 701 0	400 864 601 0	400 864 008 0	446 106 209 0	400 860 851 0	400 860 003 0

ECU Cross Reference List

Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number	Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number
400 850 073 0	400 860 855 0	400 860 003 0	N/A	400 864 516 0	400 864 522 0
400 850 309 0	400 860 855 0	400 860 003 0	N/A	400 864 517 0	400 864 522 0
446 106 215 0	400 860 853 0	400 860 004 0	N/A	400 864 562 0	400 864 565 0
N/A	400 860 853 0	400 860 004 0	N/A	400 864 575 0	400 864 565 0
N/A	400 866 731 0	400 866 164 0	N/A	400 864 518 0	400 864 566 0
400 850 718 0	400 850 718 0	400 865 013 0	N/A	400 864 519 0	400 864 566 0
N/A	400 866 739 0	400 866 166 0	N/A	400 864 561 0	400 864 566 0
N/A	400 866 794 0	400 866 167 0	N/A	400 864 574 0	400 864 566 0
N/A	400 866 795 0	400 866 166 0	N/A	400 864 576 0	400 864 566 0
N/A	400 865 260 0	400 865 045 0	N/A	TBD	400 864 568 0
N/A	400 866 699 0	400 866 169 0	N/A	TBD	400 864 569 0
N/A	400 865 254 0	400 865 043 0	N/A	400 865 751 0	400 865 731 0
N/A	400 866 687 0	400 866 166 0	N/A	400 865 752 0	400 865 731 0
N/A	400 866 694 0	400 866 164 0	N/A	400 865 753 0	400 865 731 0
N/A	400 866 684 0	400 866 169 0	N/A	400 865 754 0	400 865 731 0
N/A	400 865 058 0	400 865 014 0	N/A	400 865 755 0	400 865 731 0
N/A	400 864 369 0	400 864 009 0	N/A	400 865 756 0	400 865 731 0
N/A	400 866 737 0	400 866 166 0	N/A	400 865 760 0	400 865 731 0
N/A	400 866 738 0	400 866 166 0	N/A	400 865 762 0	400 865 731 0
N/A	400 866 247 0	400 866 166 0	N/A	400 865 770 0	400 865 731 0
N/A	400 866 248 0	400 866 169 0	N/A	400 865 772 0	400 865 731 0
N/A	400 866 257 0	400 866 164 0	N/A	400 865 773 0	400 865 731 0
N/A	400 865 257 0	400 865 043 0	N/A	400 865 763 0	400 865 732 0
N/A	400 865 256 0	400 865 044 0	N/A	400 865 764 0	400 865 732 0
N/A	400 866 689 0	400 866 164 0	N/A	400 865 769 0	400 865 732 0
N/A	400 866 688 0	400 866 168 0	N/A	400 865 746 0	400 865 733 0
N/A	400 866 736 0	400 866 164 0	N/A	400 865 747 0	400 865 733 0
N/A	400 860 122 0	400 860 140 0	N/A	400 865 748 0	400 865 733 0
N/A	400 860 131 0	400 860 140 0	N/A	TBD	400 865 734 0
N/A	400 860 132 0	400 860 140 0	N/A	400 865 765 0	400 865 735 0
N/A	400 860 133 0	400 860 140 0	N/A	400 865 766 0	400 865 735 0
N/A	400 860 134 0	400 860 140 0	N/A	400 865 750 0	400 865 736 0
N/A	TBD	400 860 912 0	N/A	400 865 771 0	400 865 736 0
N/A	400 860 900 0	400 860 913 0	N/A	400 865 774 0	400 865 736 0
N/A	400 860 901 0	400 860 913 0	N/A	TBD	400 865 736 0
N/A	400 860 904 0	400 860 914 0	N/A	400 865 280 0	400 865 738 0
N/A	TBD	400 864 082 0	N/A	400 865 600 0	400 865 738 0
N/A	400 864 088 0	400 864 088 0	N/A	400 865 789 0	400 865 740 0
N/A	400 864 515 0	400 864 088 0	N/A	TBD	400 865 741 0
N/A	400 864 054 0	400 864 522 0	N/A	400 865 803 0	400 865 743 0
N/A	400 864 055 0	400 864 522 0	N/A	400 865 805 0	400 865 743 0
N/A	400 864 056 0	400 864 522 0	N/A	400 865 807 0	400 865 743 0
N/A	400 864 057 0	400 864 522 0	N/A	400 865 810 0	400 865 743 0
N/A	400 864 071 0	400 864 522 0	N/A	400 865 275 0	400 865 743 0
N/A	400 864 072 0	400 864 522 0	N/A	400 865 277 0	400 865 743 0

ECU Cross Reference List

Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number	Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number
N/A	TBD	400 865 745 0	N/A	400 867 020 0	400 867 300 0
N/A	400 866 263 0	400 866 166 0	N/A	400 867 021 0	400 867 301 0
400 864 661 0	400 850 100 0	400 864 008 0	N/A	400 867 022 0	400 867 302 0
N/A	400 864 405 0	400 864 011 0	N/A	400 867 023 0	400 867 303 0
N/A	400 864 606 0	400 864 008 0	N/A	400 867 090 0	400 867 304 0
N/A	400 864 607 0	400 864 008 0	N/A	400 867 091 0	400 867 305 0
N/A	400 864 608 0	400 864 009 0	N/A	400 867 092 0	400 867 306 0
N/A	400 864 609 0	400 864 009 0	N/A	400 867 093 0	400 867 307 0
N/A	400 865 056 0	400 865 013 0	N/A	400 851 104 0	400 851 150 0
N/A	400 865 284 0	400 865 014 0	N/A	400 851 103 0	400 851 151 0
N/A	400 865 058 0	400 865 014 0	N/A	400 851 106 0	400 851 152 0
N/A	400 866 251 0	400 866 164 0	N/A	400 851 105 0	400 851 153 0
N/A	400 866 252 0	400 866 166 0	N/A	400 865 828 0	400 865 743 0
N/A	400 860 119 0	400 860 000 0	N/A	400 864 801 0	400 864 801 0
N/A	400 865 825 0	400 865 052 0	N/A	400 864 802 0	400 864 802 0
N/A	400 866 262 0	400 866 164 0	N/A	400 864 803 0	400 864 803 0
N/A	400 864 660 0	400 864 007 0	N/A	400 864 804 0	400 864 804 0
N/A	400 866 258 0	400 866 164 0	N/A	400 867 101 0	400 867 101 0
N/A	400 866 259 0	400 866 164 0	N/A	400 867 102 0	400 867 102 0
N/A	400 866 260 0	400 866 164 0	N/A	400 867 103 0	400 867 103 0
N/A	400 866 261 0	400 866 164 0	N/A	400 867 104 0	400 867 104 0
N/A	400 865 827 0	400 865 053 0	N/A	400 865 265 0	400 865 739 0
N/A	400 865 283 0	400 865 053 0	N/A	400 865 273 0	400 865 744 0
N/A	400 866 265 0	400 866 164 0	N/A	400 865 266 0	400 865 744 0
N/A	400 862 228 0	400 862 009 0	N/A	400 865 273 0	400 865 744 0
N/A	400 865 601 0	400 865 739 0	N/A	400 865 267 0	400 865 735 0
N/A	400 865 057 0	400 865 057 0	N/A	400 867 300 0	400 867 300 0
N/A	400 865 059 0	400 865 059 0	N/A	400 867 301 0	400 867 301 0
N/A	400 865 602 0	400 865 602 0	N/A	400 867 302 0	400 867 302 0
N/A	400 865 603 0	400 865 603 0	N/A	400 867 303 0	400 867 303 0
N/A	400 866 253 0	400 866 253 0	N/A	400 867 304 0	400 867 304 0
N/A	400 866 254 0	400 866 254 0	N/A	400 867 305 0	400 867 305 0
N/A	400 867 001 0	400 867 071 0	N/A	400 867 306 0	400 867 306 0
N/A	400 867 002 0	400 867 072 0	N/A	400 867 307 0	400 867 307 0
N/A	400 867 003 0	400 867 073 0	N/A	400 867 308 0	400 867 308 0
N/A	400 867 004 0	400 867 074 0	N/A	400 867 309 0	400 867 309 0
N/A	400 867 005 0	400 867 075 0	N/A	400 867 310 0	400 867 310 0
N/A	400 867 006 0	400 867 076 0	N/A	400 867 311 0	400 867 311 0
N/A	400 867 007 0	400 867 077 0	N/A	400 867 081 0	400 867 081 0
N/A	400 867 008 0	400 867 078 0	N/A	400 867 082 0	400 867 082 0
N/A	400 867 009 0	400 867 079 0	N/A	400 867 083 0	400 867 083 0
N/A	400 867 041 0	400 867 085 0	N/A	400 867 084 0	400 867 084 0
N/A	400 867 042 0	400 867 086 0	N/A	400 867 085 0	400 867 085 0
N/A	400 867 043 0	400 867 087 0	N/A	400 867 086 0	400 867 086 0
N/A	400 867 044 0	400 867 088 0	N/A	400 867 087 0	400 867 087 0

ECU Cross Reference List

Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number	Original ABS ECU Part Number	ECU Part Number Being Replaced	New ECU Part Number
N/A	400 867 088 0	400 867 088 0	N/A	400 867 027 0	400 867 027 0
N/A	400 865 268 0	400 865 736 0	N/A	400 867 028 0	400 867 028 0
N/A	400 865 269 0	400 865 744 0	N/A	400 867 029 0	400 867 029 0
N/A	400 867 071 0	400 867 071 0	N/A	400 851 150 0	400 851 150 0
N/A	400 867 072 0	400 867 072 0	N/A	400 851 151 0	400 851 151 0
N/A	400 867 073 0	400 867 073 0	N/A	400 851 152 0	400 851 152 0
N/A	400 867 074 0	400 867 074 0	N/A	400 851 153 0	400 851 153 0
N/A	400 867 075 0	400 867 075 0	N/A	400 851 150 0	400 851 156 0
N/A	400 867 076 0	400 867 076 0	N/A	400 851 151 0	400 851 157 0
N/A	400 867 077 0	400 867 077 0	N/A	400 851 152 0	400 851 158 0
N/A	400 867 078 0	400 867 078 0	N/A	400 851 153 0	400 851 159 0
N/A	400 867 079 0	400 867 079 0	N/A	400 864 815 0	400 864 815 0
N/A	400 867 200 0	400 867 300 0	N/A	400 864 816 0	400 864 816 0
N/A	400 867 201 0	400 867 301 0	N/A	400 864 817 0	400 864 817 0
N/A	400 867 202 0	400 867 302 0	N/A	400 864 818 0	400 864 818 0
N/A	400 867 203 0	400 867 303 0	N/A	400 867 119 0	400 867 119 0
N/A	400 867 204 0	400 867 304 0	N/A	400 867 120 0	400 867 120 0
N/A	400 867 205 0	400 867 305 0	N/A	400 867 121 0	400 867 121 0
N/A	400 867 206 0	400 867 306 0	N/A	400 867 122 0	400 867 122 0
N/A	400 867 207 0	400 867 307 0	N/A	400 862 901 0	400 862 901 0
N/A	400 867 211 0	400 867 211 0	N/A	400 862 900 0	400 862 900 0
N/A	400 867 212 0	400 867 212 0	N/A	400 867 125 0	400 867 125 0
N/A	400 867 213 0	400 867 213 0	N/A	400 867 126 0	400 867 126 0
N/A	400 867 214 0	400 867 214 0	N/A	400 867 128 0	400 867 128 0
N/A	400 867 215 0	400 867 215 0	N/A	400 867 129 0	400 867 129 0
N/A	400 867 216 0	400 867 216 0	N/A	400 862 382 0	400 862 382 0
N/A	400 867 320 0	400 867 320 0	N/A	400 864 821 0	400 864 821 0
N/A	400 867 321 0	400 867 321 0	N/A	400 864 822 0	400 864 822 0
N/A	400 867 322 0	400 867 322 0	N/A	400 864 823 0	400 864 823 0
N/A	400 867 323 0	400 867 323 0	N/A	400 864 660 0	400 864 824 0
N/A	400 867 324 0	400 867 324 0	N/A	400 867 104 0	400 867 104 0
N/A	400 867 325 0	400 867 325 0	N/A	400 867 121 0	400 867 121 0
N/A	400 867 326 0	400 867 326 0	N/A	400 867 122 0	400 867 122 0
N/A	400 867 327 0	400 867 327 0			
N/A	400 867 113 0	400 867 113 0			
N/A	400 867 114 0	400 867 114 0			
N/A	400 867 115 0	400 867 115 0			
N/A	400 867 116 0	400 867 116 0			
N/A	400 865 272 0	400 865 744 0			
N/A	400 867 016 0	400 867 016 0			
N/A	400 867 017 0	400 867 017 0			
N/A	400 867 018 0	400 867 018 0			
N/A	400 867 024 0	400 867 024 0			
N/A	400 867 025 0	400 867 025 0			
N/A	400 867 026 0	400 867 026 0			



**For further product details contact your distributor or the
WABCO Customer Care Center at 855-228-3203.**

About ZF Friedrichshafen AG

ZF is a global technology company and supplies systems for passenger cars, commercial vehicles and industrial technology, enabling the next generation of mobility. ZF allows vehicles to see, think and act. In the four technology domains Vehicle Motion Control, Integrated Safety, Automated Driving, and Electric Mobility, ZF offers comprehensive solutions for established vehicle manufacturers and newly emerging transport and mobility service providers. ZF electrifies different kinds of vehicles. With its products, the company contributes to reducing emissions and protecting the climate.

ZF, which acquired WABCO Holdings Inc. on May 29, 2020, now has 162,000 employees worldwide with approximately 260 locations in 41 countries. In 2019, the two then-independent companies achieved sales of €36.5 billion (ZF) and \$3.4 billion (WABCO). For more information, visit: www.wabco-na.com.

This publication is not subject to any update service. Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. WABCO reserves the right to revise the information presented or to discontinue the production of parts described at any time.

© Copyright 2020 WABCO North America LLC - All rights reserved - TP19061 / 09.2020

WABCO